POWERNAIL	TECHNICAL BULLETIN 09/2016 #10

Subject:	Flex Foot Adjustment Lever

Models:	Trigger Pull Models with Center Adjustment Lever

Summary: This Technical Bulletin explains how the Flex Foot Adjustment Lever is used to position the Flex Foot .

Action:

The Adjustment Lever will loosen and tighten the Flex Foot allowing for proper positioning on the tongue side of the wood. If the lever needs to be re-positioned for tightening/loosening pull down on the lever **(it is spring loaded)** and re-position it. **Note: DO NOT REMOVE SCREW IN THE CENTER OF THE LEVER)** Turning the lever Clockwise tightens and Counter clockwise loosens.