

ITEM	DESCRIPTION	PART #
1	Screw	n/a
2	Bushing	n/a
3	Exhaust Cover	n/a
4	Seal	n/a
5	Screw	n/a
6	Cylinder Cap	n/a
7	Gasket	09-20FS-5007
8	Seal	n/a
9	Spring	n/a
10	O-Ring (36.3 x 2.5)	09-20FS-5010
11	O-Ring (15.7 x 2)	09-20FS-5011
12	Valve	n/a
13	O-Ring (31.5 x 3.5)	09-20FS-5013
14	Stopped Washer	n/a
14a	O-Ring (48.5 x 2.5)	09-20FS-5014A
14b	Collar	n/a
15	O-Ring (28.3 x 3)	09-20FS-5015
16	Piston Assembly	09-20FS-5016
17	O-Ring (27.3 x 2)	09-20FS-5017
18	Cylinder	09-20FS-5018
19	Bumper	09-20FS-5019
22	Body	n/a
23	Joint Guider	09-20FS-5023
24	Safe Bracket Guider	n/a
25	Spring (Safety)	09-20FS-5025
27	Pin	n/a
28	Seal	n/a
29	Trigger Valve Head	n/a
30	Spring	n/a
31	O-Ring (5.5 x 1.5)	n/a
32	Trigger Valve Stem	n/a
33	O-Ring (15 x 1.9)	n/a
34	Trigger Valve Guider	n/a
35	Pin	n/a
36	Locking Washer	09-20FS-5036
37	Spring	n/a
38	Trigger	n/a
39	Pin	n/a
43	Screw	n/a
44	Movable Magazine Unit	n/a
45	Stopped Block	n/a
46	Spring Washer	n/a
50	Gate	09-20FS-5050
51	Fixed Magazine Unit	09-20FS-5051
52	Washer	n/a
53	Spring (Magazine, 2 count)	09-20FS-5053
54	Feeder Shoe Retainer	n/a
55	Feeder Shoe	n/a

ITEM	DESCRIPTION	PART #
56	Stopped Plate	n/a
57	Pin	n/a
58	Support	n/a
59	Torsion Spring	n/a
60	Lock	n/a
61	Screw	n/a
62	Nut	n/a
63	Softgrip Sleeve	n/a
64	O-Ring (40.2x2.3)	n/a
65	End Cap	n/a
66	Air Plug	n/a

ITEM	DESCRIPTION	PART #
70	Maunal/Instructions	09-20FS-INST
71	Stapler Foot	09-20FS-5071
72	Stapler Gate Plate	09-20FS-5072
73	Stapler Support Shoe	09-20FS-5073
74	Stapler Foot Rest	09-20FS-5074
75	Stapler Safety	09-20FS-5075
76	Knob-Footer Rest	09-20FS-5076
77	1/4-28 x 1-1/4 Cap Screw	09-20FS-5077
78	M4-0.7 x 25mm SHCS	09-20FS-5078
79	.156 Dia Spring Pin	09-20FS-5079
80	M5-0.8 x 20mm SHCS	09-20FS-5080

### POWERNAIL MODEL 20FS SCHEMATIC

